

Invaluable when the power source cannot be situated directly beside the welder, remote controls can help improve productivity and reduce welder fatigue.

Product compatibility

TITAN 231 DC FV + Kit NUM-1
 TITAN 400 DC
 NEOPULSE 320 C + Kit NUM-1
 NEOPULSE 400 G + Kit NUM-1
 NEOPULSE 400 CW + Kit NUM-1
 NEOPULSE 500 G + Kit NUM-1
 TITANIUM 230 AC/DC FV + Kit NUM-1
 TITANIUM 400 AC/DC
 NEOFEED-4W



More information

Compatible processes






MMA / TIG / MIG-MAG

How it works

An ON/OFF button switches the digital remote control unit on and off. When the digital remote control is switched on, the HMI of the power source/wire feeder will only display the current and voltage values. As soon as the HMI is switched off or disconnected, the power source/wire feeder HMI will be reactivated.

Accessories (optional extras)

RC-HD2 communication cable - 2.8 m	063907
RC-HD2 communication cable - 6 m	063914
RC-HD2 communication cable - 11 m	036925
NUM-1 kit	063938

	 mm	 kg			
	387 x 250 x 110	1.8	option	✓	10 pins