

**Invaluable when the power source cannot be situated directly beside the welder, remote controls can help improve productivity and reduce welder fatigue.**

### Product compatibility

KRONOS 400T G + Kit NUM-3  
 KRONOS 400T GW + Kit NUM-3  
 NEOMIG-i 400 G + Kit NUM-3  
 NEOMIG-i 500 G + Kit NUM-3  
 COSMOS 400 G  
 COSMOS 500 G  
 KRYPTON 231 DC + Kit NUM-3  
 KRYPTON 321 DC + Kit NUM-3  
 KRYPTON 401 DC  
 TITANIUM 321 AC/DC



More information

Supplied with neck strap

### Compatible processes






MMA / TIG / MIG-MAG

### How it works

An ON/OFF button switches the digital remote control unit on and off. When the digital remote control is switched on, the HMI of the power source/wire feeder will only display the current and voltage values. As soon as the HMI is switched off or disconnected, the power source/wire feeder HMI will be reactivated.

### Accessories (optional extras)

RC-HD3 communication cable - 2 m	079717
RC-HD3 communication cable - 6 m	079724
RC-HD3 communication cable - 10 m	079731
NUM-3 kit	081246

	 mm	 kg			
	387 x 250 x 110	1.9	option	✓	7 pins